



Revision: 1.1 - 04/13/2010

**INCLUDED IN THE KIT:**

(1)-Chrome license/light frame	(2)-M5x10mm flathead screws
(1)-Chrome backing plate	(1)-Rubber cushion
(1)-Chrome mounting base	(1)-Wire harness bag (Harley and custom installations)
(1)-6x20mm cap head SS screws	

**INSTRUCTIONS:**

Please read ALL of the instructions BEFORE beginning the installation.

We recommend the use of blue Loctite on all fasteners and mounting hardware

*NOTE: This is a custom part. Some drilling, bodywork, and/or minor fabrication will be required. Some state plates may require trimming for proper fit!*

- Carefully remove stock rear license plate and holder.
- Remove any rubber hole insulators mounted on fender (no longer required).
- Clean and wax outside fender area.
- Install supplied rubber cushion onto new mounting base.
- Insert allen mounting bolt through the chrome mounting base. Next install mounting base to fender area. Mark the area for new wire hole and drill hole in the fender for electrical wires to be run.
- Drill and deburr hole in fender for the wires to pass.
- Connect wires per color chart shown below.  
*Do not connect by matching to stock wire colors!*

**Black wire: Battery Ground: to Yamaha black**

**Blue wire: Positive (Suggestion: connect to hot" wire from a switched source): to Yamaha blue**

**Red wire: Brake signal: to Yamaha yellow**

**Brown wire: Right turn: to Yamaha green**

**Violet wire: Left turn: to Yamaha brown**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.

© 2026 Barons Custom Accessories