



Revision: 1.2 - 04/20/2010

Install Time: 1 Hour

NOTE: We recommend the use of blue Loctite on all fasteners and mounting hardware.

**INCLUDED IN THE KIT:**

1-Chrome License Holder and Frame,	4-M5X8 chrome button screws, 4-M5 Chrome Flat Washers,
1 - Chrome Frame	4-M5 Chrome Split Lock Washers

**INSTRUCTIONS:**

1. Remove rear fender from bike.
  2. Remove plastic license holder/sub fender from fender.
  3. Remove tail lamp from plastic license holder/sub fender.
  4. Install tail lamp onto new Baron License Holder using stock sheet metal screws.
  5. Install license plate into new license holder using the M5 hex screws and washers. (Note: some state plates may require trimming).
  6. Install new license holder into fender where stock plastic sub fender was removed and tighten securely.
  7. This product is not intended for use with stock turn signal assemblies. If using marker lights or other aftermarket turn signals, install according to instructions supplied by manufacturer, or by bolting to tabs provided and plugging into wire harness where stock lamps were disconnected.
- Note:* because stock fender is plastic, you will need to ground your marker lights if a separate ground wire is not provided with the lights to plug into stock ground connector in wire harness.
8. Plug in tail lamp to stock wire harness connector.
  9. Check for proper operation of tail and brake lamps, and turn signals if used.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2010 Barons Custom Accessories