



Revision: 1.1 - 02/23/2010

INCLUDED IN THE KIT:

(3) M6x10 Flathead Screws	(1) Chrome Backing Plate
(4) M5x10 Flathead Screws	(1) Chrome License Frame

INSTRUCTIONS:

Note: We recommend the use of Loctite on all fasteners and mounting hardware

Remove stock license holder from rear fender.

Install chrome backing plate with supplied M6 flathead screws into stock holes. Install with open edge down so light from the tail lamp will illuminate license plate.

Check the fit of your license plate and trim as necessary.

Install license plate frame with supplied M5 flathead screw.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories