



**Revision: 1.1 - 02/19/2010**

Please read ALL of the instructions BEFORE beginning the installation

**INCLUDED IN THE KIT:**

**Chrome Side-Mount Bracket**

**M10 chrome washer**

**INSTRUCTIONS:**

*We recommend the use of blue Loctite or other thread lock agent on all fasteners.*

- 1. Remove the lower acorn nut and washers from left shock.**
- 2. Install new Side-Mount Bracket onto stud so tab on bracket is stopped by shocks lower ring, and flange with three threaded holes faces to the left.**
- 3. Install the supplied M10 washer first, then replace acorn nut and washer - torque to 47 ft-lbs.**
- 4. You may now mount your Baron side mount license/taillight assembly (part number BA-3103-00) per instructions supplied with that kit.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2026 Barons Custom Accessories