



Revision: 1.2 - 04/12/2012

Install Time: 40 Minutes

Read this before installing these products! USE FOR TURN-SIGNAL LIGHTS ONLY DO NOT USE AS RUNNING LIGHTS. OVERHEATING WILL OCCUR AND THE PLASTIC LENS WILL MELT. WE RECOMMEND INSTALLATION OF THIS KIT BE PERFORMED BY A QUALIFIED MOTORCYCLE TECHNICIAN.

INCLUDED IN THE KIT:

(2) Bullet Marker Lights with Orange Lenses	(2) 3/8-16 x 5/8" Bolts
(2) Optional Red Lenses	(2) 3/8" Washers
(2) 3/8-16 x 1-1/4" Bolts	(2) Rubber Washers

TOOLS REQUIRED:

3/8" drill bit

INSTRUCTIONS:

1. Remove rear wheel and rear turn-signal assembly per factory shop manual procedures.
2. Remove stock 6mm fender mounting screw (you may choose to place the Bullet Lights in either the front or rear fender mounting hole location). Locate and unplug turn signal power leads from their connectors.
3. The mounting hole must be enlarged using a 3/8" drill bit.
4. Guide wire from Bullet Light through mounting hole and then through supplied washer and 3/8-16 x 1-1/4" bolt. Align Bullet Light to desired angle and tighten bolt.
5. Plug male bullet connector from Bullet Light into female connector from stock turn signal power lead.

NOTE: A proper ground must be provided for the Bullet Lights. On most models, you must either ground the fender or one of the Bullet Lights. If the optional red lens is desired, remove set-screw holding amber lens in position and replace with red lens.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.

© 2026 Barons Custom Accessories