



Revision: 1.0 - 03/18/2010

READ INSTRUCTIONS PRIOR TO INSTALLING FLOORBOARDS

INCLUDED IN THE KIT:

(1) 5/32 Long Hex Key	(2) 1/4-20x1/2 Chrome Flat Allens
(4) M10 Chrome Flat washers	(2) Floorboards
(2) 3/8-16x3/4 Flat socket Cap Screws	

INSTRUCTIONS:**Assembly**

Fasten the floorboard assembly to the S" shaped mounting bracket (Baron logo facing out) using the supplied 14mm bolt and lockwasher. Do not tighten at this time. (Barons recommends the use of Blue Loctite on this bolt).

Set fore-aft floorboard angle by installing the supplied flathead allen screw in the cam bracket at the desired angle hole. Baron floorboards set to a 15-degree position (middle hole) has been found to be most comfortable and user friendly. Tighten flathead screw. Adjust side tilt angle by moving floorboard stop screw in or out to achieve desired angle.

Now fully tighten the large 14mm mount bolt. Floorboard is ready for installation.

Installation

Remove the two bolts that attach your stock passenger peg mounting brackets to the frame and remove the stock pegs.

Install your new Baron floorboards in the same location using the supplied mounting bolts. Insert the mounting bolts (with washer) through both the floorboard assembly and fasten to your bikes frame. Be sure you dont over-tighten these bolts. It is best to use Loctite when mounting.

Adjustment of floorboard angle after installation Slightly loosen the 14mm bolt located on the backside of the mounting bracket that the floorboard is attached to.

Remove the small allen screw located on visible side of the cam bracket. Once this screw is removed, adjust the cam to the desired hole and insert and tighten the allen screw.

Re-tighten the 14mm bolt. Repeat this process on both sides.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.

© 2026 Barons Custom Accessories