



Revision: 1.1 - 12/08/2009

Install Time: 15 Minutes

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

(1) Left Floorboard	(1) Right Floorboard
---------------------	----------------------

TOOLS REQUIRED:

Pliers or Needle Nose	
-----------------------	--

INSTRUCTIONS:

1. Remove cotter pin from pivot pin on the stock foot peg - note the position of the spring.
2. Replace stock foot peg with your new Sporty Longboard, replacing stock spring in the same location and position that it was removed from. Note on V-Star 1100 Custom: do not reuse spring.
3. Replace pivot pin and secure with supplied cotter pin.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories