



BA-7061-00

**SPORTY LONGBOARD - Yamaha V-Star 1100, Honda VTX 1800
C**

Page: 1

Revision: 1.1 - 12/08/2009

Install Time: 15 Minutes

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

(1) Left Floorboard

(1) Right Floorboard

TOOLS REQUIRED:

Pliers or Needle Nose

INSTRUCTIONS:

- 1. Remove cotter pin from pivot pin on the stock foot peg - note the position of the spring.**
- 2. Replace stock foot peg with your new Sporty Longboard, replacing stock spring in the same location and position that it was removed from. Note on V-Star 1100 Custom: do not reuse spring.**
- 3. Replace pivot pin and secure with supplied cotter pin.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories