



Revision: 3.7 - 01/19/2016

Install Time: 1 Hour

We recommend the use of a factory service manual and the use of Blue Loctite on ALL threaded hardware.

INCLUDED IN THE KIT:

Chrome Triple Tree Cover & Bar Riser Adapter	(2) M12-1.25 x 45mm Cap Head Allen Bolts
(2) 1/2-13 x 1.50" Cap Head Allen Bolts	(2) M12 Lock Washers
(2) 1/2" Lock Washers	(2) M12 Flat Washers

TOOLS REQUIRED:

Box/Open End Wrenches (Metric & SAE)	Blue Loctite®
Allen Wrenches (Metric & SAE)	

INSTRUCTIONS:

NOTE: This Triple Tree Cover and Handlebar/Riser Adapter allows the use of handlebars and/or risers that are set for 3.50" spacing. This spacing is the conventional spacing used on Harley Davidson motorcycles.

SUGGESTIONS: If installing risers, in order for them to be aligned properly you should install the handlebar through each riser base and install the riser cap or caps and tighten them before tightening the riser base mount bolts. Once these mount bolts are tightened it is best to remove the conventional handlebars before proceeding with the installation.

BE ADVISED: Depending on the handlebar you are using it may be necessary to install your handlebar controls (clutch, brake and throttle) before you install the Adapter on the triple tree.

IMPORTANT: Use Blue Loctite® on ALL bolt threads for the proper installation.

1. Remove stock handlebar and risers.
2. On a work surface attach your new risers or drag bars to the new Triple Tree Cover and Handlebar/Riser Adapter by inserting the (supplied) 1/2-13 x 1.50" cap head allen bolts and lock washers into the countersunk holes in the bottom of the Adapter and thread them in.
3. In this order: Set the new Triple Tree Cover and Handlebar/Riser Adapter on the triple tree and align with the stock riser holes, install the lock washer, then flat washer on each of the M12 cap head allen bolts and thread them through the stock triple tree riser mount holes into the Adapter and tighten firmly.
4. If you are installing conventional risers and handlebar (i.e., not drag bars) you should now install and adjust your new handlebar.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2026 Barons Custom Accessories