



Revision: 1.1 - 02/19/2010

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

INCLUDED IN THE KIT:

(3) Chrome Bolt Covers w/set screws	(1) Allen Wrench
(3) 6mm SS Allen Cap Screws	

INSTRUCTIONS:

- **Remove each existing BAK mounting screw from engine and replace with supplied cap screw.**
- **Slip new chrome Bolt Cover over head of cap screw and tighten set screw with supplied allen wrench.**
- **Periodically recheck set screw tightness in Bolt Covers.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2010 Barons Custom Accessories