



BA-7800-xx – CHROME AXLE NUT COVERS

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

(2) Axle Nut Covers, chrome	(4) M6x10 set screws
(1) Honda bolt kit	

INSTRUCTIONS:

1. Slide your new Baron Axle Nut Covers into position on the bottom of each front fork leg until seated.
2. Rotate as needed for best coverage. A cut out has been provided for speedometer drive cable clearance on models so equipped.
3. Tighten (2) set screws to secure.
4. Honda models require our included **BA-7800-01, Bolt Kit** to replace stock pinch bolts (2 per fork leg).

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

© 2009 Baron Custom Accessories

Revision 5.0 (6/17/2009)