



BA-3103-00

SIDE MOUNT LICENSE - Universal Fitment (Mounting bracket required)

Page: 1

Revision: 1.8 - 02/08/2010

Install Time: 60 Minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

(1) Complete Chrome License Mount w/Cat-Eye Brake Light

INSTRUCTIONS:

NOTE: This part requires a mounting bracket sold separately

IMPORTANT: Please read ALL of the instructions BEFORE beginning the installation.

NOTES: Your new Side Mount License comes partially assembled for shipping. Please follow these simple assembly procedures prior to mounting the unit to your motorcycle.

ASSEMBLY

1. Remove four (4) license plate frame mount screws and the license plate frame from your new Baron License/Tail Light assembly.

2. Attach backing plate to the mounting bracket with supplied 6x10mm screws

3. Position license plate and install plate frame. Tighten remaining screws.

INSTALLATION

1. Wire the tail light into motorcycles wire harness as follows: (Brake light): Taillights red wire to motorcycles brake light wire. (Tail/running light): Taillights yellow wire to motorcycles running light wire. Black wire to ground. You will need approximately 30-inches of wire to properly route taillight wiring up swing arm and into wire harness.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2024 Barons Custom Accessories