



**BA-3160-00**  
**Side-Mount License Bracket**  
**Honda VTX**

**Page: 1**

**Revision: 1.1 - 02/19/2010**

This kit requires Baron part # BA-3103-00 (sold separately)

**INCLUDED IN THE KIT:**

(1) - Chrome Side-Mount Bracket	
---------------------------------	--

**INSTRUCTIONS:**

1. Remove the two top acorn nuts and washers from front of final drive unit where it attaches to drive shaft cover.
2. Install new Side-Mount Bracket onto studs so rear of bracket is angled up toward seat, and flange with the three threaded holes faces to the left.
3. Replace acorn nuts and washers, torque to 47 ft-lbs.
4. You may now mount your Baron side mount license/taillight part number BA-3103-00.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2024 Barons Custom Accessories