



BA-3160-00
Side-Mount License Bracket
Honda VTX

Revision: 1.1 - 02/19/2010

This kit requires Baron part # BA-3103-00 (sold separately)

INCLUDED IN THE KIT:

(1) - Chrome Side-Mount Bracket

INSTRUCTIONS:

- 1. Remove the two top acorn nuts and washers from front of final drive unit where it attaches to drive shaft cover.**
- 2. Install new Side-Mount Bracket onto studs so rear of bracket is angled up toward seat, and flange with the three threaded holes faces to the left.**
- 3. Replace acorn nuts and washers, torque to 47 ft-lbs.**
- 4. You may now mount your Baron side mount license/taillight part number BA-3103-00.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2021 Barons Custom Accessories