



BA-3200U Marker Light Mounting Tabs

Page: 1

Revision: 1.0 - 03/12/2010

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

2-rubber washers	2-M6x10 chrome button head screws
2-chrome washers	2-Stainless mounting tabs

INSTRUCTIONS:

The marker light mounts are intended to mount in the rear fender next to the taillight in the holes left empty by removal of the stock turn signal assembly.

Remove the stock turn signal assembly from rear fender.

Remove stock taillight.

Attach new mounting tabs with supplied hardware in the holes on either side of the taillight. Mount your favorite marker light to the tabs (we suggest Barons BA-3400U) and route marker light wires under stock taillight rubber, and through the fender with the taillight wires. Reinstall stock taillight.

Attach marker light wires to the brown (left) and green (right) turn signal wires on stock wire harness. Bundle and secure under fender with zip ties.

We suggest mounting your license plate above the taillight using Baron BA-3184U Laydown License Plate Holder.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2025 Barons Custom Accessories