



BA-7000-00

**PASSENGER SPORTBOARDS - Requires Mounting Brackets
(Sold Separately)**

Page: 1

Revision: 1.7 - 01/31/2019

Install Time: 20 Minutes

Use caution when installing, be sure to use Lockite#&174; on all threaded hardware. Be sure to tighten all threaded hardware prior to use.

INCLUDED IN THE KIT:

Left & Right Chrome Sport Boards	(2) 1/4-20 x 1-1/2" Button Heads Chrome (installed)
(2) Chrome Pivot Mounts, pre-installed	(2) M6 X 10mm Socket Set Screws SS (installed)
(2) 3/8-16 x 3/4" Chrome Bolts (installed)	

INSTRUCTIONS:

NOTE: Your new floorboards come partially assembled for shipping. Please follow these simple assembly procedures in order to install these on your motorcycle.

1. Remove the Baron Sport Boards from their packaging, you will find they come with two chrome Pivot brackets attached. The Pivots are what allows the floorboard to attach to the mounting brackets (Sold Separately) and how the boards tilting can be adjusted.
 2. Attach the Pivot to the Floorboard Mounting Bracket using the supplied hardware that comes with the floorboard brackets. The larger bolts come through the back side of the mounting bracket and thread into the 3/8-16 hole in the back of Pivot, snug the 3/8" bolts up but do not tighten. Take the small 1/4-20x 1/2" Flathead Allen screw and thread them through the small hole/s in the Pivots and into the mounting bracket.
- NOTE:** You must first select your preferred hole. (The upper hole will place the floorboards in a flat position and the lower hole/s provides an angled mounting position for added comfort and control). Once selected you may now tighten all Flathead hardware.
3. Remove stock pegs/floorboard mounts from your motorcycle.
 4. The mounting brackets are left and right side specific. Install Baron mounting brackets in same holes vacated when you removed the stock mounts using the supplied hardware.

NOTE: See specific instructions that may be included with the mounting brackets for specific instructions.

SUGGESTION: The second hole is the most preferred position.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.

© 2025 Barons Custom Accessories