



Revision: 1.8 - 02/05/2010

Install Time: 20 Minutes

Use caution when installing, be sure to use Locktite® and to tighten all bolts and hardware.

INCLUDED IN THE KIT:

(2) Chrome Baron Longboards	(2) Rubber Inserts (solid or flame - installed)
-----------------------------	---

TOOLS REQUIRED:

Various Allen Wrenches (Metric & Std)	Metric Sockets
Metric Open-end Wrenches	Phillips & Flat Screwdrivers
Pliers (Std. & Needle-nose)	Factory Service Manual

INSTRUCTIONS:

NOTE: We recommend the use of blue Loctite® on all fasteners.

1. Remove stock floorboards and install new Baron Floorboard Mount Brackets per instructions supplied with that product.
2. Loosely assemble black mounting bracket (rounded-edge side facing down) to the bottom of the Baron Longboards using supplied hardware.
3. Position new floorboard assembly on the stock floorboard mounting arm, and slide pin through to hold in place (don't use spring yet). Determine your optimal riding position by experimenting with the holes on the bottom plate (you may want to try several positions before final fastening).
4. Once you have selected your favorite leg position, remove the pin and lift Baron Floorboard assembly off the bikes mounting arm. Apply Loctite® and final-tighten all floorboard mounting bolts securely.
5. Finish installation per instructions supplied with mounting brackets.

IMPORTANT: We recommend you re-tighten all mounting bolts after 100 miles.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2025 Barons Custom Accessories