



**Revision: 1.1 - 02/19/2010**

**INCLUDED IN THE KIT:**

<b>(2) - M6 Set Screws (installed)</b>	<b>(4) - M8x20 Cap Head Screws</b>
<b>(4) - M5 Set Screws (installed)</b>	<b>(2) - Longboard Mounts</b>

**INSTRUCTIONS:**

***NOTE: We recommend the use of blue Loctite on all fasteners/mounting hardware.***

- **Unhook spring from underside of stock floorboard.**
- **Remove E-clips from stock pivot pins and remove pins. Retain pin and E-clip as they will be reused. The spring will not be reused.**
- **Install new floorboard mounts to frame where stock boards were removed, using hardware removed in previous step.**
- **Attach new Longboards onto mounting brackets in desired position using supplied M8 cap-head screws. NOTE: not all positions may be usable in all applications.**
- **After mounting screws are tightened, tighten set screw on each end of mount bracket to hold mounting screws in place.**
- **Adjust heel shifter so it does not touch floorboard during downshifts. NOTE: heel shifters are removable on most models.**
- **Use set screw on bottom of mount brackets to set desired angle to boards.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2021 Barons Custom Accessories