



Revision: 1.0 - 02/23/2010

INCLUDED IN THE KIT:

(4) M5 Set Screws	(2) Longboard Mounts
(4) M8x20 Cap Head Screws	

INSTRUCTIONS:

NOTE: We recommend the use of blue Loctite on all fasteners/mounting hardware.

Unhook spring from underside of stock floorboard

Remove E-clips from stock pivot pins and remove pins. Retain pin and E-clip, they will be reused. The spring will not be reused.

Install new floorboard mounts to frame where stock boards were removed.

Mount new Longboards onto mounts in desired position. NOTE: not all positions may be usable in all applications.

After screws are tightened, tighten set screw on each end of mount to hold mounting bolt in place.

Adjust heel shifter so it does not touch floorboard during downshifts. NOTE: heel shifters are removable on most models.

**Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2025 Barons Custom Accessories**