



Revision: 1.1 - 03/15/2010

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

(4) 8mm Socket Cap Bolts

(2) Mounting Brackets

INSTRUCTIONS:

- 1. Remove the stock floorboards by removing the pivot bolts from the bottom of the board where they attach to the frame bracket.**
- 2. Install the new Baron Longboard mount with the stock bolts and nuts.**
- 3. Install the Longboard onto the mount with the supplied M8 cap head screws. Position the boards so that you do not have interference with the heel shifter, engine guard, ect. if equipped.**
- 4. The heel strike pads on the bottom of the boards are replaceable if required after a period.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2024 Barons Custom Accessories