



Revision: 1.0 - 03/16/2010

Please read ALL of the instructions BEFORE beginning the installation

INCLUDED IN THE KIT:

| | |
|-----------------------------|------------------------------|
| (2) M10x30mm Cap Head Bolts | (1) Chrome Shifter Extension |
| (2) M10x40mm Cap Head Bolts | (2) Extension Plates |
| (1) Brake Rod Extension | |

INSTRUCTIONS:

NOTE: We recommend the use of blue Loctite on all fasteners and mounting hardware.

- 1. Disconnect shift rod from leading end of rod.**
- 2. Disconnect brake rod at both ends.**
- 3. Remove right and left side footrest assemblies from the frame.**
- 4. Install the extension plate to the frame with one stock bolt in the rear-most hole of the plate. Locate this into the rear hole in the frame.**
- 5. Install the footrest assembly to the extension plate with one M10x30mm in the front hole and one M10x40mm on the center hole of the extension plate. Repeat on the other side.**
- 6. Install the chrome shift rod extension onto the forward end of the shift rod and adjust the shift lever height. Tighten jam nut.**
- 7. Install the supplied black brake rod extension to the threaded end of the brake rod. Adjust the pedal height, tighten the jam nut and reinstall the forward end of the brake rod.**
- 8. Test ride the motorcycle and recheck all fasteners.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2021 Barons Custom Accessories