

BA-7401-00 BULLET (ISO) GRIP ENDS

Page: 1

Revision: 2.3 - 02/04/2010 Install Time: 15 Minutes CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

(2) Chromed Billet Bar Ends

INSTRUCTIONS:

- 1. Remove stock ISO Grip bar end.
- 2. Install new bar end using stock hardware.
- 3. We recommend using blue Loctite® on all hardware.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.

© 2024 Barons Custom Accessories