



**BA-7416-01 & BA-7416-01B  
1" PULLBACK RISER EXTENSIONS**

**Revision: 1.0 - 05/21/2014  
Install Time: 15 Minutes**

**CAUTION!** When installing these extensions be sure you have enough cable slack after installation for fully turning your front end.

**INCLUDED IN THE KIT:**

|                                       |                              |
|---------------------------------------|------------------------------|
| <b>(2) 1/2" Lock washers</b>          | <b>(2) 1" Extensions</b>     |
| <b>(2) 1/2-13 x 2" Hex Head Bolts</b> | <b>(1) Mount Adapter Kit</b> |

**INSTRUCTIONS:**



Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2021 Barons Custom Accessories