



Revision: 1.6 - 02/04/2010

Install Time: 30 Minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

(1) - Belt Guard	(1) - 6mm x 25mm Chromed Button-Head Screw
(2) - 6mm x 12mm Chromed Button-head Screws	(1) - Flat Cover Plate
(2) - Chromed Flat Washers	(1) - 12mm Spacer

INSTRUCTIONS:

1. Place the motorcycle on a suitable stand to safely support it while you perform the installation.
2. If your bike is equipped with a Baron Rear Pulley Cover, you will need to remove rear wheel per Yamaha shop manual procedures. Otherwise, loosen rear wheel and push forward to give drive belt as much slack as is available.
3. Remove chromed upper belt guard and plastic lower belt guard.
4. Install new Belt Guard onto motorcycle by sliding its rear section into rear pulley area first, then positioning it inline with the stock mounting locations. Fasten upper rear mounting area first with provided 6 x 12mm button-head screw and flat washer.
5. Install the front 6 x 12mm button-head screw and flat washer (sometimes you must flex the guard to get proper hole alignment on the front mount hole).
6. Position supplied flat cover plate over belt guards lower rear swingarm mounting tab (make sure this tab is not bent in toward the wheel) and install supplied 6 x 25mm button-head screw, placing supplied spacer between rear of swingarm mounting tab and Baron Belt Guard. Screw fastener into Belt Guard.
7. If removed, reinstall rear wheel per Yamaha shop manual procedures. Adjust drive belt per shop manual instructions and tighten axle to recommended specs.
8. Check for clearance in all areas, especially around the rear pulley (sometimes the tail end of belt guard may have been bent inward during packaging and shipping - if this is the case gently bend outward for clearance)
9. Install chromed, stock upper belt guard per Yamaha shop manual procedures.

NOTE: We strongly recommend the application of Loctite®, or a similar material, on the threads of all bolts.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2025 Barons Custom Accessories