



**Revision: 1.0 - 02/23/2010**

**CAUTION!** Read this before installing these products! This part is designed for the Yamaha XVZ1300AT Venture, but will work on other models

**INCLUDED IN THE KIT:**

<b>(4) M8x65mm Strainless Steel Allen Bolts</b>	<b>(2) Riser Extensions</b>
---	-----------------------------

**INSTRUCTIONS:**

*Note: We strongly recommend the application of Loctite, or a similar material, on the threads of all bolts.*

**Protect or remove fuel tank.**

**Remove riser caps from the stock risers.**

**Rest handlebars on the protected fuel tank.**

**Place riser extensions onto the stock risers.**

**Place handlebars onto riser extensions and replace the stock riser caps using supplied M8 x 65mm bolts.**

**Tighten the upper mount bolts first. Adjust handlebar for comfort, then tighten lower mount bolts to secure the bar.**

**Check for fuel tank clearance and cable routing prior to riding the motorcycle.**

*NOTE: This part has been tested to work with stock lines on Yamaha Royal Star Venture models. It has also been tested with a Baron Starbar to work with stock lines. Not for use with Yamaha chrome dash cover, or Yamaha one-piece riser cap.*

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2024 Barons Custom Accessories