



Revision: 1.3 - 02/07/2013

INCLUDED IN THE KIT:

(2) 3/8" X-Thick Flat Washer Zinc Plated
--

INSTRUCTIONS:

- 1. Place the motorcycle on a suitable stand to safely support it while you perform the installation.**
- 2. Remove forward two final-drive-member mounting bolts per Yamaha service manual procedures. Slide forward edge of new Baron Drive Shaft Cover behind frame downtube and align Shaft Covers mounting holes with final-drive-member mounting holes and replace mount bolts previously removed.**
- 3. Torque bolts to Yamaha service manual specs. NOTE: If you will be using the stock Yamaha passenger foot pegs, we recommend you install the supplied 8mm washers under the left-side foot peg bracket to space this away from the Shaft Cover so as to avoid possible contact under full suspension load. We do not recommend this foot peg be used as a boarding step" when mounting a passenger to the motorcycle. We have found this action can lead to bending of the stock foot peg mounting bracket.**

Limited Guaranty Because we cannot control the application of our products, buyer assumes risks for any and all damage caused to him or herself or any third party by virtue of any failure of these parts. Guaranty for such parts is limited to our replacement costs thereof. This guaranty is in lieu of all other guaranties or warranties express or implied, and all other such guaranties or warranties are hereby expressly disclaimed. By installation of these parts, buyer irrevocably agrees to the foregoing.

<p>Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product. © 2021 Barons Custom Accessories</p>
--