



BA-7643-00

T.O.R.K. Cover V-Star1100 (all years all models)

Page: 1

Revision: 1.1 - 03/17/2010

INCLUDED IN THE KIT:

(2) M6x20 Chrome Cap Screws

(1) Faux Engine Cover

INSTRUCTIONS:

After installing an oil filter relocation kit, attach this cover to the holes in the right crankcase cover with the supplied M6x20 screws.

**Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2021 Barons Custom Accessories**