



**BA-7643-00**

**T.O.R.K. Cover V-Star1100 (all years all models)**

**Page: 1**

**Revision: 1.1 - 03/17/2010**

**INCLUDED IN THE KIT:**

**(2) M6x20 Chrome Cap Screws**

**(1) Faux Engine Cover**

**INSTRUCTIONS:**

**After installing an oil filter relocation kit, attach this cover to the holes in the right crankcase cover with the supplied M6x20 screws.**

**Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2025 Barons Custom Accessories**