



Revision: 2.6 - 01/02/2013

Install Time: 10 Minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

INCLUDED IN THE KIT:

| | |
|--|-----------------------------|
| (2) Axle Nut Covers | (4) M6x10 Set Screws |
| (4) M8-1.25 x 30mm SS Button Head Cap Bolts | |

INSTRUCTIONS:

- 1. Slide your new Baron Axle Nut Covers into position on the bottom of each front fork leg until seated.**
- 2. Rotate as needed for best coverage. A cut out has been provided for speedometer drive cable clearance on models so equipped.**
- 3. Tighten set screws (2 per Axle Nut Cover) to secure.**
- 4. Honda models require the included M8-1.25 x 30mm bolts to replace stock pinch bolts (2 per fork leg).**

NOTE: Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2025 Barons Custom Accessories