



**BA-7800U & BA-7800B**

**CHROME/BLACK AXLE NUT COVERS - Honda, Kawasaki and Yamaha Models**

**Page: 1**

**Revision: 2.6 - 01/02/2013**

**Install Time: 10 Minutes**

**CAUTION!** We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the install.

**INCLUDED IN THE KIT:**

(2) Axle Nut Covers	(4) M6x10 Set Screws
(4) M8-1.25 x 30mm SS Button Head Cap Bolts	

**INSTRUCTIONS:**

1. Slide your new Baron Axle Nut Covers into position on the bottom of each front fork leg until seated.
2. Rotate as needed for best coverage. A cut out has been provided for speedometer drive cable clearance on models so equipped.
3. Tighten set screws (2 per Axle Nut Cover) to secure.
4. Honda models require the included M8-1.25 x 30mm bolts to replace stock pinch bolts (2 per fork leg).

**NOTE:** Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Baron bears no responsibility on installation costs associated with this product.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2025 Barons Custom Accessories