



Revision: 1.5 - 02/23/2010

These shortened side stands are for lowered motorcycles only Installation on a standard-height bike may result in an unstable condition!

INSTRUCTIONS:

Road Star/Warrior installation:

- 1. Place motorcycle on a suitable stand and ensure it is secure.**
- 2. Remove nut from top of side stand pivot bolt.**
- 3. Remove pivot bolt and spring.**
- 4. Clean and grease pivot area.**
- 5. Install new side stand with stock bolt and supplied special washer. The flat" of the washer will contact the safety switch when stand is down.**
- 6. Reinstall the spring.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2024 Barons Custom Accessories