



Revision: 1.5 - 08/05/2014

Install Time: 20 Minutes

We recommend you read all instructions fully before starting. Use Loctite® on all threaded hardware.

**INSTRUCTIONS:**

1. Safely secure the bike in the upright position.
2. Remove the passenger floorboards and install the comfort blocks with the supplied hardware and thread locker. The blocks can be bolted on in an array of positions to give you a wide variety of adjustability.
3. The left side block can be identified by the length wise cut away for clearing the primary.
4. Reinstall the passenger floorboards using the stock hardware and thread locker. The adjustability of both the comfort blocks and the stock floorboards should give your passenger the ability to choose a foot rest position that is perfect for their riding style.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. LA Choppers bears no responsibility on installation costs associated with this product.  
© 2021 LA Choppers