



LA-7090-10

2010+ Touring Passenger Floorboard Comfort Kit

Page: 1

Revision: 1.5 - 08/05/2014

Install Time: 20 Minutes

We recommend you read all instructions fully before starting. Use Loctite® on all threaded hardware.

INSTRUCTIONS:

- 1. Safely secure the bike in the upright position.**
- 2. Remove the passenger floorboards and install the comfort blocks with the supplied hardware and thread locker. The blocks can be bolted on in an array of positions to give you a wide variety of adjustability.**
- 3. The left side block can be identified by the length wise cut away for clearing the primary.**
- 4. Reinstall the passenger floorboards using the stock hardware and thread locker. The adjustability of both the comfort blocks and the stock floorboards should give your passenger the ability to choose a foot rest position that is perfect for their riding style.**

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. LA Choppers bears no responsibility on installation costs associated with this product.

© 2024 LA Choppers