



Revision: 1.2 - 01/19/2011

CAUTION! We strongly recommend that a qualified Honda Technician install this kit since the carburetor must be removed from the motorcycle. Please read all directions before starting.

**INCLUDED IN THE KIT:**

(1) Billet BAK Cover	(2) 1/4-28 x 1 13/16" Hex Bolt Zinc
(1) M6 x 60 Socket Cap Screw	(1) Jet Kit BA-2461-00
(1) M5 x 10 Socket Cap Screw SS	(1) BAK Backing Plate VTX 1300
(1) M6 Fender Washer	(2) Aluminum Filter Spacer
(5) M6x12mm Phillips Head Stainless Screws	(1) Reed Valve Block Off Kit BA-2561-00
(1) 1/4" x 1 1/2" Plastic Spacer, Black	(1) Filter Raincoat
(3) M5 x 16 Flat Head Screw	(1) Re-useable Performance Air Filter
(2) 1/4" Lock Washer	

**TOOLS REQUIRED:**

Shop Manual	7/16" Open End Wrench
3, 4, & 5mm Allen Wrenches	#2 Phillips Screw Driver

**INSTRUCTIONS:**

1. Remove fuel tank according to Honda service manual procedures.
2. Remove air cleaner from right side of bike.
3. Remove idle cable holder from back of stock air filter.
4. Install idle cable holder to rear of the new BAK backing plate just below the nylon nipple. Bracket should face outward and slightly down when BAK is mounted.
5. Install Jet Kit according to instructions provided in Jet Kit box.
6. Install Reed Valve Black-off Kit using the instructions provided with that kit. *Installation of this kit is optional.*
7. Place 1/4-28 x 1 13/16" Zinc Hex Bolts & 1/4" lock washers into center holes of backing plate from the backside. It may help to use some masking tape to hold them in place.
8. Install new backing plate to carburetor and secure with three flat-head screws provided (blue Loctite is recommended). Install supplied M6 screw and washer through the front of the backing plate in the hole nearest the idle cable holder and then through plastic spacer. Secure into stock bracket on the engine.
9. Connect crankcase vent tube onto nylon nipple.
10. Insert aluminum filter spacers onto mount bolts, then place filter in groove on backing plate and place cover plate onto filter. Gently guide the cover plate around filter to seat and seal filter.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2021 Barons Custom Accessories



**11. Secure cover plate with screws used in step 7.**

**12. Re-install fuel tank. Remember to replace the vacuum line on the petcock and the vent on the rear underside of the tank.**

**Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2021 Barons Custom Accessories**